

Human Transforming Growth Factor Beta Detection ELISA Kit

Catalog # 6809

For Research Use Only - Not Human or Therapeutic Use

PRODUCT SPECIFICATIONS

DESCRIPTION: ELISA Kit to quantify Human TGF-β

FORMAT: Pre-coated 96-well ELISA Plate with removeable strips

ASSAY TYPE: Sandwich ELISA

ASSAY TIME: 4 hours

STANDARD RANGE: 2000 - 31 pg/ml

NUMBER OF SAMPLES: Up to 40 (duplicate) samples/plate

SAMPLE TYPES: Culture Media, Serum, and Plasma

RECOMMENDED SAMPLE DILUTIONS: 1:1 (at least)

CHROMOGEN: TMB (read at 450 nm)

STORAGE: -20°C for 12 months

VALIDATION DATA: Intra-Assay (7.5-10.9%)/Inter-Assay (4.9-11%)/Spiking Test (113-141%)

NOTES: N/A



Human Transforming Growth Factor Beta Detection ELISA Kit

Catalog # 6809

For Research Use Only – Not Human or Therapeutic Use

Chondrex, Inc. provides a human transforming growth factor beta (TGF-β) quantitative ELISA kit for cell culture, serum, and plasma samples.

KIT COMPONENTS

Item	Quantity	Amount	Storage
Human TGF-β Standard (68091)	2 vials	2000 pg, lyophilized	-20°C
Detection Antibody (68093)	2 vials	50 μl	-20°C
Solution B - Sample/Standard/Detection Antibody Dilution Buffer (67015)	1 Bottle	50 ml	-20°C
Solution D - Streptavidin Peroxidase Dilution Buffer (9055)	1 Bottle	20 ml	-20°C
Streptavidin Peroxidase (9029)	2 vials	50 μl	-20°C
TMB (90023)	2 vials	200 µl	-20°C
Chromogen Dilution Buffer (90022)	1 Bottle	20 ml	-20°C
Stop Solution - 2N Sulfuric Acid (9016)	1 Bottle	10 ml	-20°C
Wash Buffer, 20X (9005)	1 Bottle	50 ml	-20°C
Capture Antibody Coated 96-Well ELISA Plate (Red)	1 each	8-well Strips x12	-20°C

NOTES BEFORE USING ASSAY

- NOTE 1: It is recommended that the standard and samples be run in duplicate.
- NOTE 2: Warm up all buffers to room temperature before use.
- NOTE 3: Crystals may form in Wash Buffer, 20X when stored at cold temperatures. If crystals have formed, warm the wash buffer by placing the bottle in warm water until crystals are completely dissolved.
- NOTE 4: Measure exact volume of buffers using a serological pipet, as extra buffer is provided.
- NOTE 5: Cover the plate with plastic wrap or a plate sealer after each step to prevent evaporation from the outside wells of the plate.
- NOTE 6: For partial reagent use, please see the assay protocol's corresponding step for the appropriate dilution ratio. For example, if the protocol dilutes 50 μ l of a stock solution in 10 ml of buffer for 12 strips, then for 6 strips, dilute 25 μ l of the stock solution in 5 ml of buffer. Partially used stock reagents may be kept in their original vials and stored at -20°C for use in a future assay.
- NOTE 7: This kit contains animal components from non-infectious animals and should be treated as potential biohazards in use and for disposal.

© 2022 Chondrex, Inc. All Rights Reserved, 6809 2.1



ASSAY OUTLINE

Add 100 µl of diluted standards and samples into wells



Incubate at room temperature for 2 hours. Wash plate.

Add 100 µl of diluted Detection Antibody



Incubate at room temperature for 1 hour. Wash plate.

Add 100 µl of diluted Streptavidin Peroxidase



Incubate at room temperature for 30 minutes. Wash plate.

Add 100 µl of TMB solution




Incubate at room temperature for 25 minutes.

Add 50 µl of Stop Solution



Read plates at 450 nm/630 nm


PLATE MAPPING



© 2022 Chondrex, Inc. All Rights Reserved, 6809 2.1

ASSAY PROCEDURE

1. Prepare Standard Dilutions: The recommended standard range is 31 - 2000 pg/ml. Dissolve one vial of human TGF-β standard in 1 ml of Sample/Standard/Detection Antibody Dilution Buffer (Solution B) for the 2000 pg/ml standard. Then serially dilute it with Solution B. For example, mix 250 µl of the standard (2000 pg/ml) with an equal volume of Solution B to make a 1000 pg/ml solution, and then repeat it five more times for 500, 250, 125, 63, and 31 pg/ml solutions. The remaining 2000 pg/ml standard stock may be stored at -20°C for use in a second assay. Chondrex, Inc. recommends making fresh serial dilutions for each assay.



2. Prepare Samples:

Cell Culture Media: Remove cell debris and insoluble precipitate by centrifuging at 10,000 rpm for 5 minutes. When not in use, store the supernatant samples at -20°C; avoid repeat freeze-thaw cycles.

Serum*: Clot blood samples by incubating samples at room temperature for 2 hours. Collect serum by centrifuging samples at 10,000 rpm for 5 minutes. When not in use, store the serum supernatant samples at -20°C; avoid repeat freeze-thaw cycles.

Plasma*: Collect plasma samples with the use of anticoagulants such as heparin. Collect plasma by centrifuging samples at 10,000 rpm for 5 minutes within 30 minutes of blood collection. When not in use, store the plasma supernatant samples at -20°C; avoid repeat freeze-thaw cycles.

NOTE: Using lipemic (cloudy) samples may affect assay results. The stored samples must be centrifuged at 10,000 rpm for an additional 5 minutes before the assay.

NOTE: This kit can only detect the active form of TGF- β . If you need to assay total TGF- β levels in samples, the latent form of TGF- β in samples must be activated. Please refer to the Appendix for activation protocols.

Dilution: Dilute samples at least 1:1 with Solution B depending on the estimated TGF- β level in the samples. Two to three different sample dilutions are recommended if the TGF- β levels in the samples are unknown.

NOTE: Samples must be diluted with Solution B to maintain optimal assay conditions.

- 3. Add Standards and Samples: Add 100 µl of Solution B (blank), standards, and samples to designated wells in duplicate and incubate at room temperature for 2 hours.
- 4. Dilute Wash Buffer: Dilute 50 ml of Wash Buffer, 20X in 950 ml of distilled water (1X wash buffer). Wash the plate with 1X wash buffer at least 3 times using a wash bottle with manifold or an automated plate washer. Empty the plate by inverting it and blotting on a paper towel to remove excess liquid. Do not allow the plate to dry out.



5. **Add Detection Antibody Solution**: Prepare the detection antibody solution with Sample/Standard/Detection Antibody Dilution Buffer (Solution B) as shown in the following table. Add 100 μl of detection antibody solution to each well and incubate at room temperature for 1 hour.

Strip #	Detection Antibody (µI)	Solution B (ml)
2	17	1.7
4	25	3.3
6	50	5.0
8	66	6.6
10	82	8.2
12	100	10.0

- 6. **Wash**: Wash the plate with 1X wash buffer at least 3 times using a wash bottle with manifold or an automated plate washer. Empty the plate by inverting it and blotting on a paper towel to remove excess liquid. Do not allow the plate to dry out.
- 7. Add Streptavidin Peroxidase Solution: Prepare streptavidin peroxidase solution with Streptavidin Peroxidase Dilution Buffer (Solution D) as shown in the following table. Add 100 µl of streptavidin peroxidase solution to each well and incubate at room temperature for 30 minutes.

Strip#	Streptavidin Peroxidase (µI)	Solution D (ml)
2	17	1.7
4	25	3.3
6	50	5.0
8	66	6.6
10	82	8.2
12	100	10.0

- 8. **Wash**: Wash the plate with 1X wash buffer at least 3 times using a wash bottle with manifold or an automated plate washer. Empty the plate by inverting it and blotting on a paper towel to remove excess liquid. *Do not allow the plate to dry out.*
- 9. **Add TMB Solution**: Dilute one vial of TMB in 10 ml of Chromogen Dilution Buffer just prior to use. Add 100 μl of TMB solution to all wells immediately after washing the plate and incubate for 25 minutes at room temperature.

Strip#	TMB (µI)	Chromogen Dilution Buffer (ml)	
2	34	1.7	
4	66	3.3	
6	100	5.0	
8	132	6.6	
10	164	8.2	
12	200	10.0	

- 10. **Stop**: Stop the reaction with 50 μl of 2N Sulfuric Acid (Stop Solution) to each well.
- 11. **Read Plate**: Read the OD values at 450 nm. If the OD values of samples are greater than the OD values of the highest standard, reassay the samples at a higher dilution. A 630 nm filter can be used as a reference.


© 2022 Chondrex, Inc. All Rights Reserved, 6809 2.1



CALCULATING RESULTS

- Average the duplicate OD values for the blank, standards, and test samples.
- 2. Subtract the "blank" (B) values from the averaged OD values in step 1.
- 3. Plot the OD values of standards against the concentration of human TGF-β (pg/ml). Using a log/log plot will linearize the data. Figure 1 shows a representative experiment where the standard range is 31 2000 pg/ml.
- The pg/ml of TGF-β in test samples can be calculated using regression analysis.

Figure 1 - A Typical Standard Curve for the Human TGF-β Detection ELISA Kit



ASSAY VALIDATION

Table 1 - Reproducibility Data for the Human TGF-β Detection ELISA Kit

Test	63 pg/ml	250 pg/ml	1000 pg/ml
Intra-Assay CV (%)	7.5	10.9	8.6
Inter-Assay CV (%)	4.9	11.0	10.3
Spike Test* (%)	113%	115%	141%

^{*} Known amounts of human TGF- β were added to samples and then diluted with Sample/Standard/Detection Antibody Dilution Buffer (Solution B).

TROUBLESHOOTING

For frequently asked questions about assays and ELISAs, please see Chondrex, Inc.'s ELISA FAQ for more information.

Phone: 425.702.6365 or 888.246.6373

Fax: 425.882.3094

APPENDIX

Reagent Preparation

To activate latent TGF- β to the immunoreactive form, the following 1N HCl and 1.2N NaOH/0.5M HEPES solutions are required. These solutions can be kept at room temperature for up to one month.

1 N HCI: 10 ml

- 1. Prepare 9.2 ml of distilled water in a 15 ml centrifuge tube.
- Add 0.8 ml of 12 N HCl.

1.2 N NaOH/0.5 M HEPES: 10 ml

- 1. Weigh 1.2 g HEPES in a 15 ml centrifuge tube and add 7.5 ml of distilled water.
- 2. Add 1.2 ml of 10 N NaOH. After mixing, adjust the final volume to 10 ml with distilled water.

NOTE: When each batch of the reagents are prepared, test a neutralization condition using negative control samples. After adding 1.2 N NaOH/0.5 M HEPES to samples, use pH indicator paper to assess the pH of the samples. The pH should be between 7.0 and 8.0.

Sample Activation

Cell Culture Supernatant and Urine Samples

- 1. Take 100 μ l of samples and add to a 0.5 ml or 1 ml centrifuge tube. Add 20 μ l of 1 N HCl.
- 2. Vortex and incubate at room temperature for 10 minutes.
- Add 20 µl of 1.2 N NaOH/0.5 M HEPES.
- 4. Vortex and dilute the sample using the kit Solution B to at least a 1:1 or higher dilution.
- Assay samples.

NOTE: When calculating final sample values, use 2.8 as the sample dilution factor if a 1:1 dilution was used.

Serum and plasma samples

- 1. Take 50 μl of samples and add to a 0.5 ml or 1 ml centrifuge tube. Add 10 μl of 1N HCl.
- 2. Vortex and incubate at room temperature for 10 minutes.
- 3. Add 10 µl of 1.2 N NaOH/0.5 M HEPES.
- 4. Vortex and dilute the sample using the kit Solution B to at least a 1:1 or higher dilution.
- 5. Assay samples.

NOTE: When calculating final sample values, use 2.8 as the sample dilution factor if a 1:1 dilution was used.

Phone: 425.702.6365 or 888.246.6373

Fax: 425.882.3094